

QUICK START INFORMATION

To view the latest support documentation, visit our website <http://www.zenitharca.com/>. Documentation is available under the Support menu.

For live technical support and warranty requests, please navigate to our support portal <https://support.zenithara.net>. Your login credentials for the support portal have been emailed to you. If you have not received login credentials please contact your authorized Zenith ARCA reseller.

You will need the Zenith ARCA service tag number located on the device for support and warranty requests.

Default ARCA Login Credentials

Default Name: administrator

Default Password: *arca*

Default Support Login Credentials

Default Name: email address provided to reseller

Default Password: *arcasupport*